


Start Configure Hardware Configure Display Configure Test Adjust PID TEST Data Graph Compare Report Security



- Trq1
- A1
- W1
- Wo1
- Eff1

| Cursors: | X | Y |
|----------|---|---|
| | | |
| | | |

Curve Fit Only

| Type | Order |
|--------------------------|-------|
| Torque 1 (mN.m) Y1 Poly. | 5 |
| Amps 1 Y2 Poly. | 5 |
| Watts IN 1 Y3 Poly. | 5 |
| Watts OUT 1 Y4 Poly. | 5 |
| Efficiency 1 Y5 Poly. | 9 |

Refresh

Auto Y Axis Auto X Axis

Save Fit

Current Data:

Speed 1 (RPM) x Export Save Print

Comments